

INDUSTRIAL DIN RAIL RS232 TO RS485 ISOLATOR

OPERATION MANUAL



DECISION
Computer International Co., Ltd.

TABLE OF CONTENTS

CHAPTERS

1. Introduction.....	1
2. Unpacking Information.....	3
3. Hardware Installation.....	4
4. Hardware Configuration.....	5

APPENDICES

A. Warranty Information	13
B. Data Sheet.....	16



CHAPTER 1

INTRODUCTION

The industrial RS232 to RS485 photo isolator provides bi-direction RS232 signals to RS485 signals conversion features, which are used to expand long haul communication distance for multi-drop RS485 communication. The industrial RS232 to RS485 photo isolator allows the input signals to be completely prevent up to 5000Vrms, which offers customers a unique combination of protection, speed, and versatility for DIN-rail mount industrial data communications applications. There are 3 LED indicators correspond to Tx, Rx, and power signals. A 250mA, 24 VDC power input for industrial standard.

The features of the industrial RS232 to RS485 photo isolator are:

- EIA RS232 to EIA RS485 isolator input and output.
- Heavy-duty optical couplers and a transformer isolated DC-to-DC converter to provide significantly higher electrical isolation - 5000V DC surge (1 minute), 5000V rms continuous.
- Support Tx, Rx, RTS, CTS, DTR, DSR, SG signals for RS232, and TRD+, TRD-, SG signals for RS485.
- Communication speeds up to 230 K bps.
- Transmit distance up to 4000ft.
- Three LED indicators correspond to Tx(green), Rx(yellow), and power(red) signals.
- A 250mA, 24 VDC (range from 21.6 to 26.4) power input for industrial standard.
- Provides Din Rail mountable package which uses Polyamide UL94(V0) material, and its types are TS-35, TS-32.



- Life expectancy for relay: 100 million operations at signal level load.
- Allow the photo input signals to be completely floated and prevent the ground loops.
- Operating temperature from 0C° to 70C°.



CHAPTER 2

UNPACKING INFORMATION

☞ **Check that your industrial RS232 to RS485 photo isolator package includes the following items:**

- Industrial RS232 to RS485 photo isolator.
- DB9 or DB25 (option) Female expansion cable.
- Shield cable.
- User manual.
- Warranty form.




CHAPTER 3

HARDWARE CONFIGURATION

The industrial RS232 to RS485 photo isolator are shown is the following





1. Signal Assignment for Isolator Box


The signal assignment for isolator box is defined as following. Consider the top view of isolator box, there are 13 signals are defined as:

Transmit Data	Receive Data		Shield Ground
Clear To Send	Request To Send		
Signal Ground1			
Data Terminal Ready	Data Set Ready		Signal Ground2
	0V		Transmit Receive Data+
	24V	-	Transmit Receive Data-

Please note that the DTR and DSR signals are short by internal circuit of the box.

2. DB25 Connector Assignments for RS232

The communication interface follows the EIA RS232 standard. The signal assignments for a standard Data Terminal Equipment (DTE) DB25 connector are shown below:




Pin	DB25 # Signal Name	RS- 232C Name	Signal Direction	color
2	Transmit Data(TxD)	BA	Output	brown
3	Receive Data(RxD)	BB	Input	Red
4	Request to Send(RTS)	CA	Output	blue
5	Clear to Send(CTS)	CB	Input	yellow
6	Data Set Ready(DSR)	CC	Input	green
7	Signal Ground(SG)	AB	Common	black

20	Data Terminal Ready(DTR)	CD	Output	purple
----	--------------------------	----	--------	--------

3. DB9 Connector Assignments for RS232

The signal assignments for a standard Data Terminal Equipment (DTE) DB9 connector are shown below:



Pin	DB9 # Signal Name	RS-232C Name	Signal Direction	color
2	Receive Data(RxD)	BB	Input	red
3	Transmit Data(TxD)	BA	Output	brown
4	Data Terminal Ready(DTR)	CD	Output	purple
5	Signal Ground(SG)	AB	Common	black
6	Data Set Ready(DSR)	CC	Input	green
7	Request to Send(RTS)	CA	Output	Blue

8	Clear to Send(CTS)	CB	Input	Yellow
---	--------------------	----	-------	--------

4. DB25 Connector Assignments for RS485

The communication interface follows the EIA RS485 standard. The signal assignments for a standard DB25 connector are shown below:

Pin	Description	color
2	Transmit Data+/ Receive Data+(TRD+)	brown
3	Transmit Data-/Receive Data-(TRD-)	Red
7	Signal Ground	black

5. DB9 Connector Assignments for RS485

The communication interface follows the EIA RS485 standard. The signal assignments for a standard DB9 connector are shown below:

Pin	Description	color
2	Transmit Data-/Receive Data-(TRD-)	red
3	Transmit Data+/ Receive Data+(TRD+)	brown
5	Signal Ground	black

CHAPTER 4


APPLICATIONS

The applications of industrial RS232 to RS485 photo isolator are shown is the following:

1. Connect to RS485 Device

RS232 to RS485 photo isolator


Device



2. For Long Haul Distance Communication

RS232 to RS485 photo isolator

RS232 to RS485 photo isolator



APPENDIX A

WARRANTY INFORMATION

A.1 Copyright

Copyright 2002, 2003 DECISION COMPUTER INTERNATIONAL CO., LTD. All rights reserved. No part of RS232 to RS485 isolator may be reproduced, transmitted, transcribed, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of DECISION COMPUTER INTERNATIONAL CO., LTD.

Each piece of RS232 to RS485 isolator package permits user to use only on a single computer, a registered user may use the program on a different computer, but may not use the program on more than one computer at the same time.

Corporate licensing agreements allow duplication and distribution of specific number of copies within the licensed institution. Duplication of multiple copies is not allowed except through execution of a licensing agreement. Welcome call for details.

A.2 Warranty Information

DECISION warrants that for a period of one year from the date of purchase (unless otherwise specified in the warranty card) that the goods supplied will perform according to the specifications defined in the user manual. Furthermore that the RS232 to RS485 isolator product will be supplied free from defects in materials and workmanship and be fully functional under normal usage.



In the event of the failure of an RS232 to RS485 isolator product within the specified warranty period, DECISION will, at its option, replace or repair the item at no additional charge. This limited warranty does not cover damage resulting from incorrect use, electrical interference, accident, or modification of the product.

All goods returned for warranty repair must have the serial number intact. Goods without serial numbers attached will not be covered by the warranty.

Transportation costs for goods returned must be paid by the purchaser. Repaired goods will be dispatched at the expense of RS232 to RS232 isolator.

To ensure that your RS232 to RS485 isolator product is covered by the warranty provisions, it is necessary that you return the Warranty card.

Under this Limited Warranty, DECISION's obligations will be limited to repair or replacement only, of goods found to be defective as specified above during the warranty period. DECISION is not liable to the purchaser for any damages or losses of any kind, through the use of, or inability to use, the RS232 to RS485 isolator product.

DECISION reserves the right to determine what constitutes warranty repair or replacement.

Return Authorization: It is necessary that any returned goods are clearly marked with an RA number that has been issued by DECISION. Goods returned without this authorization will not be attended to.

