



SMARTLAB
USB 4 CHANNELS RELAY OUTPUT
4 CHANNELS PHOTO ISOLATOR
INPUT BOARD

OPERATION MANUAL



DECISION GROUP INC.





TABLE OF CONTENTS

CHAPTERS

1. Introduction.....	1
2. Hardware Configuration.....	5
3. Diagnostic under Windows/XP	9
4. Programming under Windows/XP and Linux.....	9

APPENDICES

A. Warranty Information.....	10
B. Data Sheet.....	12





CHAPTER 1

INTRODUCTION

USB 4 channels relay output / photo isolator input board provides photo couple digital input and relay output channels. The photo isolator input part provides 4 photo couple digital input channels, which allow the input signals to be completely floated and prevent the ground loop. The relay output part provides 4 relays to drive 4 different output channels. Each relay channel can be used to control ON/ OFF of external devices, to drive external power relays, to activate alarms... etc.

The USB 4 channels relay output / photo isolator input board provides Plug and Play (PnP) features, it is a programmable I/O interface board for PC/486, Pentium, or compatibles. The on board high speed 8051 uC provides USB functions run at 12Mbps full speed or 1.5Mbps low speed.

❖ **The features of USB 4 channels relay output / photo isolator input board are:**

- USB2.0 with Plug and Play (PnP) features.
- High speed 8051 uC core.
- Support USB ID selection to identify USB device.
- Support 4 photo couple input channels and 4 relay output channels.
- Allow the photo input signals to be completely floated and prevent the ground loops.
- 8 LED correspond to 4 input and 4 output ports activation status.
- By using PC817 photo couple chips.
- Power supplied from External DC +5V.




- For photo couple input channel, the isolation voltage is 5000V, maximum load voltage is 30V, maximum input current is 50mA forward.
- Activation voltage of photo input:
When short jumpers (input range from 0 to 20V DC)
0 to 3.3V inactive
4.5 to 20V active
When open jumpers (input range from 0 to 30V DC)
0 to 17.6V inactive
18 to 30V active
- Maximum contact rating is 220V/AC, 120V/DC 1AMP, minimum response time is 1ms, maximum contact resistance is 0.1 OHM.
- Suitable for Linux, MS/Windows ... etc.
- Operating temperature range from 0 to 33C.
- Relative humidity rage from 0 to 90%.

❖ **PACKAGE CONTENTS:**

- SMARTLAB USB 4 channels relay output / photo isolator input board
- USB cable.
- Decision Studio and User's manual CD.
- Two Different Connector Types can be selected:
Standard: European P.C.B type terminal blocks
Professional: Pluggable terminal blocks

Optional

- Extension board with DB9 : RS232 or RS422/485
- PCB Carrier





CHAPTER 2

HARDWARE CONFIGURATION

Before you use USB 8 channels relay output board, please ensure that the jumpers and switches setting. The proper jumper and switches settings for the 8 channels relay output board are described in the following.

2.1 Switch Settings


1. S1 Reset



The S1 switch is used to reset 8051, the signal assignments are shown in the following.

Pin	Signals
3,4	Reset SW+
1,2	Reset SW-

2. S2 USB ID





The S2 switch is used to identify USB board ID. Please set different board ID to each board (do not duplicate ID setting).

1	2	3	4	ID
ON	ON	ON	ON	--
OFF	ON	ON	ON	14
ON	OFF	ON	ON	13
OFF	OFF	ON	ON	12
ON	ON	OFF	ON	11
OFF	ON	OFF	ON	10
ON	OFF	OFF	ON	9
OFF	OFF	OFF	ON	8
ON	ON	ON	OFF	7
OFF	ON	ON	OFF	6
ON	OFF	ON	OFF	5
OFF	OFF	ON	OFF	4
ON	ON	OFF	OFF	3
OFF	ON	OFF	OFF	2
ON	OFF	OFF	OFF	1
OFF	OFF	OFF	OFF	0

3. Download revised firmware


When the S2 switch is set to ON ON ON ON status, means down load revised firmware. please follow the steps shown in the following:

1. Set S2 to ON ON ON ON.
2. Run USBBootloader program to down load revised firmware.



2.2 Jumper Settings

Input Voltage Range Selection (JP1 to JP4)



JP1 to JP4 are used to select input voltage range. The JP1 is used to select photo couple input channel 0, and JP2 is used to select photo couple input channel 1 ... etc. When short the jumper, the input voltage range from 0 to 20V, and the active voltage form 4.5 to 20V. When open the jumper, the input voltage range from 0 to 30V, and the active voltage from 18 to 30V.

Jumper	Input Voltage	Inactive Voltage	Active Voltage
open	0 to 30V	0 to 17.6V	18 to 30V
short	0 to 20V	0 to 3.3V	4.5 to 20V

2.3 USB Connector

1. USB Connector

The USB connector is connected to computer USB port by using USB cable.



2.4 LED Status

1. LED1

The LED1 is an indicator to show the power is supplied normally.


2. LED2



The LED2 is an indicator to warning the USB link status. When it lights, it means USB connection works normally, otherwise it is fail.


2.5 Connector and Jumper for Serial Communication

1. The connector of serial communication(J2)



To use RS422/RS485/RS232, please connect J2 to extension board by 10 pins flat cable. (Optional)

2. Enable Serial Port (J3)



J3 is used enable serial port communication, when short the J3, means enable serial port, otherwise, when open the J3, the serial port communication is disable.

2.6 Connector Assignments

The photo isolator input signal and relay output signal pin assignments are shown in the below.

1. Input Signal Assignments

Pin	Signal	Description
1	SGND	Signal Ground
2	+5V	+5V
3	IN0+	Opto-isolator Ch. 00 + Input
4	IN0-	Opto-isolator Ch. 00 - Input
5	IN1+	Opto-isolator Ch. 01 + Input



6	IN1-	Opto-isolator Ch. 01 - Input
7	SGND	Signal Ground
8	+5V	+5V
Pin	Signal	Description
1	SGND	Signal Ground
2	+5V	+5V
3	IN2+	Opto-isolator Ch. 02 + Input
4	IN2-	Opto-isolator Ch. 02 - Input
5	IN3+	Opto-isolator Ch. 03 + Input
6	IN3-	Opto-isolator Ch. 03 - Input
7	SGND	Signal Ground
8	+5V	+5V

2. Output Signal Assignments

Pin	Signal	Description
1	NC0	Relay Ch. 00 - Output
2	COM0	Relay Ch. 00 - Output
3	NO0	Relay Ch. 00 - Output
4	NC1	Relay Ch. 01 - Output
5	COM1	Relay Ch. 01 - Output
6	NO1	Relay Ch. 01 - Output
7	SGND	Signal Ground
8	+5V	+5V
Pin	Signal	Description
1	NC2	Relay Ch. 02 - Output
2	COM2	Relay Ch. 02 - Output
3	NO2	Relay Ch. 02 - Output
4	NC3	Relay Ch. 03 - Output
5	COM3	Relay Ch. 03 - Output
6	NO3	Relay Ch. 03 - Output
7	SGND	Signal Ground
8	EXT+5V	External DC +5V 3A Power In



CHAPTER 3

DIAGNOSTIC UNDER WINDOWS/XP

USB Test Program.exe is a diagnostic program to test your USB devices under Windows/XP.

User can get USB Test Program.exe programs from Decision Studio CD.

CHAPTER 4

SOFTWARE PROGRAMMING UNDER WINDOWS/XP AND LINUX

Under Windows, we provide function library and dll file for users to program the device in supported language. You can find manual “USBDII_Manual.pdf” and demo code in VB/VC/Delphi from Decision Studio CD.

Under Linux, we provide .c source to allow user directly to access device. You can find manual and example in “dcihid-0.5.1.tgz”.





APPENDIX A

WARRANTY INFORMATION

A.1 Copyright

Copyright DECISION COMPUTER INTERNATIONAL CO., LTD. All rights reserved. No part of SmartLab software and manual may be produced, transmitted, transcribed, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of DECISION COMPUTER INTERNATIONAL CO., LTD.

Each piece of SmartLab package permits user to use SmartLab only on a single computer, a registered user may use he program on a different computer, but may not use the program on more than one computer at the same time.

Corporate licensing agreements allow duplication and distribution of specific number of copies within the licensed institution. Duplication of multiple copies is not allowed except through execution of a licensing agreement. Welcome call for details.

A.2 Warranty Information

SmartLab warrants that for a period of one year from the date of purchase (unless otherwise specified in the warranty card) that the goods supplied will perform according to the specifications defined in the user manual. Furthermore that the SmartLab product will be supplied free from defects in



APPENDIX B

DATA SHEET

SHARP

PC817 Series

PC817 Series

High Density Mounting Type Photocoupler

- Lead forming type (I type) and taping reel type (P type) are also available. (PC817/PC817P)
- TÜV (VDE0884) approved type is also available as an option.

■ Features


1. Current transfer ratio
(CTR: MIN. 50% at $I_T = 5\text{mA}$, $V_{CE} = 5\text{V}$)
2. High isolation voltage between input and output ($V_{iso} : 5000\text{V}_{rms}$)
3. Compact dual-in-line package
PC817 : 1-channel type
PC827 : 2-channel type
PC837 : 3-channel type
PC847 : 4-channel type
4. Recognized by UL, file No. E64380

■ Applications

1. Computer terminals
2. System appliances, measuring instruments
3. Registers, copiers, automatic vending machines
4. Electric home appliances, such as fan heaters, etc.
5. Signal transmission between circuits of different potentials and impedances

■ Outline Dimensions

(Unit : mm)



* In the absence of confirmation by device specification sheets, SHARP takes no responsibility for any defects that occur in equipment using any of SHARP's devices, shown in catalogs, data books, etc. Contact SHARP in order to obtain the latest version of the device specification sheets before using any SHARP's device.*

SHARP

PC817 Series

■ Absolute Maximum Ratings

(Ta = 25°C)

Parameter	Symbol	Rating	Unit
Input	Forward current	I _F	50 mA
	Peak forward current	I _{FM}	1 A
	Reverse voltage	V _R	6 V
	Power dissipation	P	70 mW
Output	Collector-emitter voltage	V _{CEO}	35 V
	Emitter-collector voltage	V _{ECO}	6 V
	Collector current	I _C	50 mA
	Collector power dissipation	P _C	150 mW
	Total power dissipation	P _{tot}	200 mW
	Isolation voltage	V _{iso}	5 000 V _{rms}
	Operating temperature	T _{op}	-30 to +100 °C
	Storage temperature	T _{stg}	-55 to +125 °C
	Soldering temperature	T _{sd}	260 °C

*1 Pulse width: ≤100μs, Duty ratio: 0.001

*2 40 to 60% RH, AC for 1 minute


*3 For 10 seconds

■ Electro-optical Characteristics

(Ta = 25°C)

Parameter	Symbol	Conditions	MIN.	TYP.	MAX.	Unit
Input	Forward voltage	V _F I _F = 20mA	-	1.2	1.4	V
	Peak forward voltage	V _{FM} I _{FM} = 0.5A	-	-	3.0	V
	Reverse current	I _R V _R = 4V	-	-	10	μA
	Terminal capacitance	C _t V = 0, f = 1kHz	-	30	250	pF
Output	Collector dark current	I _{CDO} V _{CE} = 20V	-	-	10 ⁻⁷	A
	*4 Current transfer ratio	CTR I _F = 5mA, V _{CE} = 5V	50	-	600	%
Transfer characteristics	Collector-emitter saturation voltage	V _{CE(sat)} I _F = 20mA, I _C = 1mA	-	0.1	0.2	V
	Isolation resistance	R _{ISO} DC500V, 40 to 60% RH	5 × 10 ¹⁰	10 ¹¹	-	Ω
	Floating capacitance	C _f V = 0, f = 1MHz	-	0.6	1.0	pF
	Cut-off frequency	f _c V _{CE} = 5V, I _C = 2mA, R _L = 100Ω, -3dB	-	80	-	kHz
	Response time	Rise time t _r	-	4	18	μs
		Fall time t _f	-	3	18	μs

*4 Classification table of current transfer ratio is shown below.

Fig. 1 Forward Current vs.
Ambient Temperature

Model No.	Rank mark	CTR (%)
PC817A	A	80 to 160
PC817B	B	130 to 260
PC817C	C	200 to 400
PC817D	D	300 to 600
PC8*7AB	A or B	80 to 260
PC8*7BC	B or C	130 to 400
PC8*7CD	C or D	200 to 600
PC8*7AC	A, B or C	80 to 400
PC8*7BD	B, C or D	130 to 600
PC8*7AD	A, B, C or D	80 to 600
PC8*7	A, B, C, D or No mark	50 to 600

* : 1 or 2 or 3 or 4

SHARP

PC817 Series


Fig. 2 Collector Power Dissipation vs.
Ambient Temperature

Fig. 3 Peak Forward Current vs. Duty Ratio






Fig. 4 Current Transfer Ratio vs.
Forward Current

Fig. 5 Forward Current vs. Forward Voltage

Fig. 6 Collector Current vs.
Collector-emitter VoltageFig. 7 Relative Current Transfer Ratio vs.
Ambient Temperature

SHARP

PC817 Series



Fig. 8 Collector-emitter Saturation Voltage vs.
Ambient TemperatureFig. 9 Collector Dark Current vs.
Ambient Temperature

Fig.10 Response Time vs. Load Resistance








Fig.11 Frequency Response



Test Circuit for Response Time




Test Circuit for Frequency Response

Fig.12 Collector-emitter Saturation
Voltage vs. Forward Current

● Please refer to the chapter "Precautions for Use"

■ FEATURES

- 2 Form C Contact
- DIL Pitch Terminals
- High Reliability Bifurcated Contact
- Conforms to FCC Part 68 1500V Surge and Dielectric Strength 1000VAC
- Fully sealed
- UL File No. E147052



■ COIL RATING (at 20 °C)

Nominal Voltage (VDC)	Coil Resistance ($\Omega \pm 10\%$)	Nominal Current (mA)	Pick-Up Voltage (VDC)	Drop-Out Voltage (VDC)	Maximum Allowable Voltage(VDC)	Power Consumption (mW)
5	167	30	3.5	0.5	6.0	150
6	240	25	4.2	0.6	7.2	150
9	540	16.6	6.3	0.9	10.8	150
12	960	12.5	8.4	1.2	14.4	150
24	2880	8.3	16.8	2.4	28.8	200
48	7680	6.25	33.6	4.8	57.6	300

■ ORDERING INFORMATION

BT-12 S


Coil Voltage	Coil Sensitivity
See Coil Rating	S : 150~300mW low consumption type

*Nil : Power Consumption up to 560mW available upon request



■ SPECIFICATIONS

Model No.		BT
Contact Arrangement		2 Form C
Contact Type		Bifurcated
Contact Material		AgPd+Au Clad
Contact Resistance		Max. 60m Ω (initial)
Contact Rating (at Resistive Load)	Max. Switching Voltage	220VAC, 150VDC
	Max. Switching Current	2A
	Max. Switching Power	30W(DC), 50VA(AC)
	Rated Load	1.25A 24VDC 0.5A 100VAC
Dielectric Strength		
Between Coil & Contacts		1000VAC(1 minute)
Between Contacts		1000VAC(1 minute)
Surge Strength		1500V
Operate Time		Max. 6m Sec
Release Time		Max. 4m Sec
Ambient Temperature		-30°C~+80 °C
Insulation Resistance		Min. 1000M Ω at 500VDC
Vibration Resistance		1.5mm D.A. 10-55HZ
Shock	Functional	10G
	Destruction	100G
Mechanical Life		2 x 10 ⁷ operations (at no load)
Electrical Life (Resistive Load)		2 x 10 ⁶ operations at 1mA 20m VAC
		2 x 10 ⁶ operations at 20mA 20 VDC
		1 x 10 ⁵ operations at 1.25A 24 VDC
		1 x 10 ⁵ operations at 0.5A 100 VAC
Weight		Approx. 6g

DIMENSIONS(mm)



General Tolerance ±0.3

WIRING DIAGRAM
(Bottom View)PC board pattern (mm)
(Bottom View)

General Tolerance ±0.1